



250 SE Timber Avenue, Redmond, Oregon 97756 Phone 541 923-2233 Fax 541 923-2255

SERVICE ADVISORY

SA016-0028

Subject: Evolution Nose Gear Tow Warning Decal

Date: March 21, 2016

Towing your aircraft without following the correct towing procedures could cause nose gear issues. To be sure that you or anyone handling your Evolution does follow the procedure laid out, Lancair requests that all Evolution owners install the enclosed tow warning decal to the nose gear strut on the Evolution. Please be sure you are familiar with the tow procedures laid out in the included tow procedure laminated card as well as those in the Pilots Operating Handbook. While the aircraft is parked where others might tow it, be sure the tow procedures card is placed where it can be seen and that the people are aware of its location.

INSTALLATION

To apply the tow warning decal, locate the center of the strut with the nose straight. Temporarily place the decal such that the center mark is in the nose wheel straight position. If you are unsure it is placed in the center, remove all weight from the nose gear and the strut will self-center. Adjust the decal as necessary. Once placed in the correct position firmly press to finish applying the decal.

Shown is the finished result.

